



LOVATO ELECTRIC S.P.A.

24020 GORLE (BERGAMO) ITALIA  
VIA DON E. MAZZA, 12  
TEL. 035 4282111  
TELEFAX (Nazionale): 035 4282200  
TELEFAX (International): +39 035 4282400  
Web [www.LovatoElectric.com](http://www.LovatoElectric.com)  
E-mail [info@LovatoElectric.com](mailto:info@LovatoElectric.com)

(I) **MICRO PLC E HMI**  
Domande frequenti

(GB) **MICRO PLCs AND HMI**  
Frequently asked questions

**LRD...**

E' possibile collegare ad un modulo base LRD un modulo di espansione LRE con alimentazione ausiliaria diversa da quella del modulo base? Es. Modulo base LRD con alimentazione 24VDC e modulo di espansione LRE con alimentazione 100-240VAC o viceversa.

Si, è possibile abbinare moduli base con moduli di espansione con tensione di alimentazione differente, in quanto ogni singolo modulo LRD o LRE ha alimentazione separata.

Is it possible to connect to an LRD base module an LRE expansion module with an auxiliary power supply different from that of the base module? Eg LRD base module with 24VDC supply and LRE expansion module with 100-240VAC supply or vice versa.

Yes, it is possible to combine basic modules with expansion modules with different power supply voltage, because each LRD or LRE module has a separate power supply input stage.