



LOVATO ELECTRIC S.P.A.

24020 GORLE (BERGAMO) ITALIA
 VIA DON E. MAZZA, 12
 TEL. 035 4282111
 TELEFAX (Nazionale): 035 4282200
 TELEFAX (International): +39 035 4282400
 Web www.LovatoElectric.com
 E-mail info@LovatoElectric.com

① **FINECORSA, MICROINTERRUTTORI E INTERRUTTORI A PEDALE**
 Domande frequenti

② **LIMIT MICRO AND FOOT SWITCHES**
 Frequently asked questions

KB..., KC..., KM..., KN...

La posizione iniziale delle leve incluse sulle teste degli azionatori può essere modificata?

La posizione delle leve può essere configurata a 360° ruotando l'azionatore con passi di 15°.

E' possibile orientare le teste azionatori oppure sono fisse nella posizione di fornitura?

Le teste azionatore dei finecorsa serie KB, KC, KM e KM sono orientabili; l'accoppiamento tra testa azionatore e custodia consente l'orientamento ogni 45°.

Can the starting position of the levers included in the actuators be modified?

Levers position can be completely rotated over 360° with 15° steps.

Is it possible to rotate the operating heads or are they fixed in the supplied position?

Operating heads of limit switches series KB, KC, KM e KM can be rotated; the joint between operating head and case let the have 45° regulation steps.