



LOVATO ELECTRIC S.P.A.

24020 GORLE (BERGAMO) ITALIA
VIA DON E. MAZZA, 12
TEL. 035 4282111
TELEFAX (Nazionale): 035 4282200
TELEFAX (International): +39 035 4282400
Web www.LovatoElectric.com
E-mail info@LovatoElectric.com

F066IGB11_21

(I) COMMUTATORI DI RETE AUTOMATICI Domande frequenti

(GB) AUTOMATIC TRANSFER SWITCH CONTROLLERS Frequently asked questions

ATL6..., ATL800, ATL900

Sulla gamma ATL l'alternanza di generatori è possibile?
Come funziona?

L'alternanza dei generatori è una funzione implementabile con ATL6, ATL800 e ATL900. La centralina tiene conto della massima differenza di lavoro tra i due generatori (Es. 10h). Se la differenza dei contatori di funzionamento dei due generatori raggiunge la soglia fissata il generatore spento verrà avviato e si assisterà allo scambio del carico con conseguente spegnimento del generatore precedentemente attivo.

Is alternation of generators possible on the ATL range?
How does it work?

The alternation of generators is a function that can be implemented with ATL6, ATL800 and ATL900. The control unit considers the maximum working difference between the two generators (e.g. 10h). If the difference in the operating hour counters of the two generators reaches the set threshold, the switched off generator will be started and there will be the exchange of the load with consequent switching off the previously active generator