



**LOVATO ELECTRIC S.P.A.**

24020 GORLE (BERGAMO) ITALIA  
 VIA DON E. MAZZA, 12  
 TEL. 035 4282111  
 TELEFAX (Nazionale): 035 4282200  
 TELEFAX (International): +39 035 4282400  
 Web [www.LovatoElectric.com](http://www.LovatoElectric.com)  
 E-mail [info@LovatoElectric.com](mailto:info@LovatoElectric.com)

① **CONTATTORI MODULARI E ALTRI DISPOSITIVI**  
 Domande frequenti

Ⓒ **MODULAR CONTACTOR AND OTHER DEVICES**  
 Frequently asked questions

**CN..., CNM...**

### **Come funziona un contattore modulare a comando manuale serie CNM?**

I contattori CNM hanno un selettore frontale a 3 posizioni: A, O, I.

**Posizione A:** funzionamento come contattore.

**Posizione O:** contattore permanentemente aperto anche nel caso in cui venga alimentata la bobina.

**Posizione I:** contattore chiuso manualmente (senza alimentazione alla bobina). Alla prima alimentazione della bobina il selettore ritorna automaticamente in posizione A.

### **How does it work a modular contactor CNM series with manual control?**

CNM contactors have a front handle with 3 positions: A, O, I.

**Position A:** contactor function.

**Position O:** contactor permanently switched off, even in case of coil control voltage is present.

**Position I:** contactor closed manually; as soon as the coil is supplied the handle automatically moves to A position.