



LOVATO ELECTRIC S.P.A.

24020 GORLE (BERGAMO) ITALIA
 VIA DON E. MAZZA, 12
 TEL. 035 4282111
 TELEFAX (Nazionale): 035 4282200
 TELEFAX (International): +39 035 4282400
 Web www.LovatoElectric.com
 E-mail info@LovatoElectric.com

① **RELE' INDUSTRIALI**
 Domande frequenti

Ⓜ **GENERAL PURPOSE RELAYS**
 Frequently asked questions

HR30..., HR40..., HR50...

Installando i relè sullo zoccolo, la corrente nominale è limitata a 10A. I relè ad 1 contatto in scambio hanno una corrente nominale di 16A, come posso raggiungere tale prestazione quando i relè sono installati sullo zoccolo di fissaggio?

È possibile raggiungere la prestazione di 16A mettendo in parallelo i terminali dello zoccolo: usare un cavo di sezione adeguata alla corrente per mettere in parallelo i due terminali "COM" e i due terminali "NA" oppure "NC" secondo le esigenze di comando del relè.

Current is limited to 10A when relays are mounted in the socket. Relays with one changeover contact can reach a nominal current of 16A, how can I reach this performance when the relays are mounted in the socket?

The 16A current can be reached with parallel connection of the socket's terminals: a cable of an appropriate size for the circuit current shall be used to connect in parallel the two "COM" terminals and the two "NO" or "NC" terminals depending on the relay's command function requirements.