

I **COMMUTATORI DI RETE AUTOMATICI**
Domande frequenti**GB** **AUTOMATIC TRANSFER SWITCH CONTROLLERS**
Frequently asked questions**ATL800, ATL900****È possibile modificare un Layout di impianto se è disponibile tra quelli proposti?**

Se il Layout proposto sul manuale di ATL800 e ATL900 non rispecchiasse l'applicazione da implementare è possibile considerare la funzione del PLC integrato nelle centraline.

In questo caso si potranno disabilitare alcuni breakers in particolari condizioni al fine di adattare l'applicazione. La funzione ammessa è solamente quella di disabilitazione: non potrà essere chiuso un breaker se il layout in origine, alla specifica condizione lo prevede aperto.

Per accedere alla funzione PLC è necessario collegarsi alla centralina ATL tramite il connettore CX01 e il software gratuito Xpress.

Is it possible to change a plant layout if it is available among those proposed?

If the Layout proposed in the ATL800 and ATL900 manual does not reflect the application to be implemented, it is possible to consider the function of the PLC integrated in the control units.

In this case, some breakers can be disabled in particular conditions in order to adapt the application. The function allowed is only that of disabling: a breaker cannot be closed if the layout originally foresees it open under the specific condition.

To access the PLC function, it is necessary to connect to the ATL control unit via the CX01 connector and through the free Xpress software.