

I **INTERRUTORI SEZIONATORI**
Domande frequenti**GB** **SWITCH DISCONNECTORS**
Frequently asked questions**GA...****Come avviene l'accoppiamento tra i sezionatori della serie GA con le aste di sezione 7mm?**

Gli interruttori sezionatori della serie GA sono compatibili con le aste di prolunga GAX7... con sezione da 5mm. Per l'impiego della maniglia GAX66N(B) con i sezionatori GA030A, GA063...160A è però necessario l'impiego di un'asta GAX7...AN con sezione da 7mm. In questo caso è necessario prevedere l'impiego l'accessorio GAX60B che adatta il foro per aste con sezione da 5mm a quelle con sezione da 7mm.

Tutti gli interruttori sezionatori GA... sono omologati UL98? In cosa consiste la conformità alla norma UL98?

Nei circuiti di alimentazione (feeder circuit) è obbligatorio usare interruttori sezionatori omologati UL98, mentre sui circuiti utenza (branch circuit) si possono usare interruttori sezionatori omologati UL60947-4-1 (ex UL508). Gli interruttori sezionatori UL98 hanno caratteristiche costruttive specifiche diverse dagli interruttori sezionatori UL60947-4-1 (ex UL508) come, ad esempio, la distanza minima tra i terminali. Per questo motivo sono omologati UL98 solo gli interruttori sezionatori della seconda taglia meccanica: GA030..., GA63...125...

How is the coupling between the GA series switch disconnectors and the 7mm extension shaft?

GA series switch disconnectors are compatible with GAX7... extension shafts with 5mm section. To use the GAX66N(B) handle with the GA030A, GA063 ... 160A disconnectors, however, it is necessary to use a GAX7...AN shaft with a 7mm section. In this case it is necessary to use the GAX60B accessory which adapts the hole for shafts with a 5mm section to those with a 7mm section.

Are all the GA... switch disconnectors UL98 compliant?

In a feeder circuit it is mandatory to use UL98 switch disconnectors, whereas in a branch circuit UL60947-4-1 (ex UL508) switch disconnectors can be used. Switch disconnectors UL98 compliant have different features compared to UL60947-4-1 (ex UL508) switch disconnectors, for instance the minimum clearance between terminals. That's why only size 2 GA... switch disconnectors are UL98 compliant: GA030..., GA63...125...