



**LOVATO ELECTRIC S.P.A.**

24020 GORLE (BERGAMO) ITALIA  
 VIA DON E. MAZZA, 12  
 TEL. 035 4282111  
 TELEFAX (Nazionale): 035 4282200  
 TELEFAX (International): +39 035 4282400  
 Web [www.LovatoElectric.com](http://www.LovatoElectric.com)  
 E-mail [info@LovatoElectric.com](mailto:info@LovatoElectric.com)

① **COLONNE E SEGNALATORI LUMINOSI**  
 Domande frequenti

② **SIGNAL TOWERS AND BEACONS**  
 Frequently asked questions

**LTN...**

**È sempre necessario installare il tubo di prolunga  
 LTN50P... / LTN70P...?**

Sì, il tubo di prolunga consente di unire il modulo di cablaggio LTN50WM... / LTN70WM... con la base di fissaggio LTN50B... / LTN70B... In particolare, è necessario impiegare tubi di prolunga con estremità filettata LTNP...T con tutte le basi di fissaggio ad esclusione della base plastica per fissaggio a parete [LTN50BP2](#) / [LTN70BP2](#).

**Is it always mandatory to install the extension tube  
 LTN50P... / LTN70P...?**

Yes, extension tube allow to fit the wiring module LTN50WM... / LTN70WM... with the fixing base LTN50B... / LTN70B... Particularly extension tubes with threaded end LTNP...T have to be used for all the fixing baes except for [LTN50BP2](#) / [LTN70BP2](#) suitable for wall mounting.