

LOVATO ELECTRIC S.P.A.

24020 GORLE (BERGAMO) ITALIA  
VIA DON E. MAZZA, 12  
TEL. 035 4282111  
TELEFAX (Nazionale): 035 4282200  
TELEFAX (Internazionale): +39 035 4282400  
Web www.LovatoElectric.com  
E-mail info@LovatoElectric.com

## TEMPORIZZATORI Domande frequenti


## TIME RELAYS Frequently asked questions

### TM...

#### Come vengono impostati i timer serie TM... (no NFC)?

I temporizzatori serie TM... hanno a bordo dei trimmer di colore arancio necessari per poter impostare:

- La funzione desiderata, in caso di timer multifunzione.
- Il fondo scala.
- Il tempo di regolazione all'interno del fondo scala.



In questo esempio 1s di Fondo scala e un'impostazione di temporizzazione impostata su 5, ci indica una temporizzazione del 50% del fondo scala, cioè 0.5s.


#### Quali sono le dimensioni dei timer serie TM...?

I temporizzatori serie TM... hanno tutti la dimensione, come da norma DIN43880, di un solo modulo, ovvero 17.5mm.

#### How is it possible to set TM... series timers (not NFC version)?

The TM... timer series... has on board some orange trimmers those allow to set:

- The desired function, in case of multifunction timer.
- The end scales.
- The adjustment time of the end scale.



In this example the first trimmer is set to 1s and the second trimmer is set to 5, this means that 50% of the end scale must be counted, that is 0.5s.

#### What are the dimensions of the TM series timers...?

The TM... series timers all have the size, as per DIN43880 standard, of a single module, that is 17.5mm.