



LOVATO ELECTRIC S.P.A.

24020 GORLE (BERGAMO) ITALIA  
VIA DON E. MAZZA, 12  
TEL. 035 4282111  
TELEFAX (Nazionale): 035 4282200  
TELEFAX (International): +39 035 4282400  
Web [www.LovatoElectric.com](http://www.LovatoElectric.com)  
E-mail [info@LovatoElectric.com](mailto:info@LovatoElectric.com)

F041IGB06\_21

① **INTERRUTORI SEZIONATORI**  
Domande frequenti

Ⓒ **SWITCH DISCONNECTORS**  
Frequently asked questions

**GL0200..., GLX900, GLX901**

**È possibile trasformare un GL0200C1 in un GL0200C1UL installando i separatori di fase GLX900?**

Aggiungendo i separatori di fase GLX900/GLX901 all'interruttore sezionatore GL0200C1 non si ottiene un dispositivo omologato UL98 in quanto la marcatura del prodotto non è in linea ai requisiti UL. Per ottenere un interruttore sezionatore omologato UL98 si deve ordinare il codice GL0200C1UL.

**Is it possible to transform the GL0200C1 in GL0200C1UL by adding the phase barrier GLX900?**

The addition of the phase barriers GLX900/GLX901 to the switch disconnecter GL0200C1 does not lead to have a device UL98 homologated since product marking would not be in compliance with UL requirements. If the UL98 homologation is required, the right part number to be ordered is GL0200C1UL.