



LOVATO ELECTRIC S.P.A.

24020 GORLE (BERGAMO) ITALIA
 VIA DON E. MAZZA, 12
 TEL. 035 4282111
 TELEFAX (Nazionale): 035 4282200
 TELEFAX (International): +39 035 4282400
 Web www.LovatoElectric.com
 E-mail info@LovatoElectric.com

① RELE' DIFFERENZIALI DI TERRA Domande frequenti

Ⓜ EARTH LEAKAGE RELAYS Frequently asked questions

Posso utilizzare i relè differenziali Lovato di tipo A, per applicazioni dove è richiesto un tipo AC?

I relè differenziali di tipo AC sono adatti per correnti differenziali alternate.

I relè differenziali di tipo A sono adatti per correnti differenziali:

- Alternate;
- Pulsante unidirezionale;
- Parzializzata angolo di ritardo
- Pulsante unidirezionale con componente continua sovrapposta

I tipo A coprono quindi anche le caratteristiche della tipologia AC.

Can I use Lovato type A RCDs for applications where an AC type is required?

AC type residual current relays are suitable for alternating residual currents.

Type A residual current relays are suitable for residual currents:

- Alternate;
- One-way button;
- Partialized delay angle
- One-way push button with overlapping continuous component

The type A therefore also cover the characteristics of the type AC.